

Macro Twin Lite MT-24EX Compatibility Information 兼容資料

MT-24EX		Normal Shooting 正常拍攝											Wireless Shooting (as a Master unit) 無線拍攝 (作為主控單元)						
Camera 相機	Type 類型	Max. Sync Speed (sec.) 最高閃燈同步速度 (秒)	Flash Metering System 閃燈測光系統			Manual Flash 手動閃光	High-speed Sync 高速同步	FE Lock 閃燈鎖定	Flash Exposure Compensation 閃燈曝光補償		Flash Exposure Bracketing 閃燈包圍曝光	Modeling Flash 造型閃光	Second-curtain Sync 後簾同步	Manual Focusing Lamp 手動對焦指示燈	Optical Pulse Transmission 光脈串傳輸				
			E-TTL II	E-TTL	TTL				Flash 閃光燈	Camera 相機					E-TTL II/E-TTL Auto/flash E-TTL II/E-TTL 自動閃光	Manual flash 手動閃光	High-speed Sync 高速同步	Max No of Firing Group 最多支援燈組	
EOS 800D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 77D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 5D Mark IV	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS-1D X Mark II	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 80D	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 1300D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS M3	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 760D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 750D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS SDS R	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS SDS	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS M2	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 7D Mark II	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 70D	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 1200D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 100D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 700D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 6D	A	1/180	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS M	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 650D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS-1D X	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 5D Mark III	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 1100D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 600D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 60D/60Da	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 550D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS-1D Mark IV	A	1/300	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 7D	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 500D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 5D Mark II	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 50D	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 1000D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 450D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 40D	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS-1Ds Mark III	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS-1D Mark III	A	1/300	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 400D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 30D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 5D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS-1D Mark II N	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 350D	A	1/200	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS-1Ds Mark II	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 200D/20Da	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS-1D Mark II	A	1/250	o	x	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 300D	A	1/200	x	o	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 10D	A	1/250	x	o	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS-1Ds	A	1/250	x	o	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS D60	A	1/200	x	o	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS-1D	A	1/500	x	o	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS D30	A	1/200	x	o	x	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 300X	A	1/125	o	x	x	o	o	o	o	x	o	o	o	o	o	o	o	o	1 (Group C)
EOS 30V / 33V	A	1/125	o	x	o <sup>1</sup>	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 3000V	A	1/90	x	o	x	o	o	o	o	x	o	o <sup>2</sup>	o	o	o	o	o	o	1 (Group C)
EOS 300V	A	1/90	x	o	o <sup>1</sup>	o	o	o	o	x	o	o	o	o	o	o	o	o	1 (Group C)
EOS 66	A	1/90	x	o	o <sup>1</sup>	o	o	o	o	x	o	o	o	o	o <sup>3</sup>	o	o	o	1 (Group C)
EOS 30/33	A	1/125	x	o	o <sup>1</sup>	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS-1V	A	1/250	x	o	o <sup>1</sup>	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS 300	A	1/90	x	o	o <sup>1</sup>	o	o	o	o	x	o	o <sup>2</sup>	o	o	o <sup>3</sup>	o	o	o	1 (Group C)
EOS 88	B	1/90	x	x	o	o	x	x	o	x	o	x	o	o	x	o	x	o	1 (Group C)
EOS-3	A	1/200	x	o	o <sup>1</sup>	o	o	o	o	o	o	o	o	o	o	o	o	o	1 (Group C)
EOS IX 7	A	1/125	x	o	o <sup>1</sup>	o	o	o	o	x	o	o <sup>2</sup>	o	o	o <sup>3</sup>	o	o	o	1 (Group C)
EOS IX	A	1/200	x	o	o <sup>1</sup>	o	o	o	o	o	o	o <sup>2</sup>	o	o	o <sup>3</sup>	o	o	o	1 (Group C)
EOS 500N	A	1/90	x	o	o <sup>1</sup>	o	o	o	o	x	o	o <sup>2</sup>	o	o	o <sup>3</sup>	o	o	o	1 (Group C)
EOS 50E	A	1/125	x	o	o <sup>1</sup>	o	o	o	o	o	o	o <sup>2</sup>	o	o	o <sup>3</sup>	o	o	o	1 (Group C)
EOS-1N RS	B	1/250	x	x	o	o	x	x	o	o	o	x	o	o	x	o	x	o	1 (Group C)
EOS 888	B	1/90	x	x	o	o	x	x	o	x	o	x	o	o	x	o	x	o	1 (Group C)
EOS-1N	B	1/250	x	x	o	o	x	x	o	o	o	x	o	o	x	o	x	o	1 (Group C)
EOS 500	B	1/90	x	x	o	o	x	x	o	x	o	x	o	o	x	o	x	o	1 (Group C)
EOS 5	B	1/200	x	x	o	o	x	x	o	x	o	x	o	o	x	o	x	o	1 (Group C)
EOS 1000FN	B	1/90	x	x	o	o	x	x	o	x	o	x	o	o	x	o	x	o	1 (Group C)
EOS 100	B	1/125	x	x	o	o	x	x	o	x	o	x	o	o	x	o	x	o	1 (Group C)
EOS 1000F QD	B	1/90	x	x	o	o	x	x	o	x	o	x	o	o	x	o	x	o	1 (Group C)
EOS 700	B	1/125	x	x	o	o	x	x	o <sup>4</sup>	x	o <sup>4</sup>	o <sup>4</sup>	o	o	x	o <sup>5</sup>	x	o	1 (Group C)
EOS 10	B	1/125	x	x	o	o	x	x	o	x	o	x	o	o	x	o	x	o	1 (Group C)
EOS RT	B	1/125	x	x	o	o	x	x	o	x	o	o	o	o	x	o	x	o	1 (Group C)
EOS-1	B	1/250	x	x	o	o	x	x	o	x	o	x	o	o	x	o	x	o	1 (Group C)
EOS 630	B	1/125	x	x	o	o	x	x	o	x	o	o	o	o	x	o	x	o	1 (Group C)
EOS 850	B	1/125	x	x	o	o	x	x	x	x	x	x	x	o	x	x	x	o	1 (Group C)
EOS 750 QD	B	1/125	x	x	o	o	x	x	x	x	x	x	x	o	x	x	x	o	1 (Group C)
EOS 620	B	1/250	x	x	o	o	x	x	x	x	x	x	o	o	x	o	x	o	1 (Group C)
EOS 650	B	1/125	x	x	o	o	x	x	x	x	x	x	o	o	x	o	x	o	1 (Group C)

\*1: Enabled by Speedlite's custom function / 透過自訂功能啟動  
 \*2: If [C, Fn-02] (Modeling flash) is set to [1] (Enabled: Test firing button) or [2] (Enabled with both button), modeling flash is possible / 須設定自訂功能C:Fn-02 (造型閃光) 為 [1]: 啟動 (測試閃燈按鈕) 或 [2]: 啟動 (兩個按鈕皆可) 才可使用造型閃光  
 \*3: Single slave group control / 只支援一組從屬燈組控制  
 \*4: For EOS 700, enabled with shutter speed-priority AE / 使用EOS 700相機, 設定為快門先決自動曝光後啟動  
 \*5: For EOS 700, the aperture will be fixed at f/5.6 / 使用EOS 700相機, 光圈值會固定為f/5.6

Disclaimer: The information contained in this document is for general reference only. The Specification and performance of the products tested may vary due to modification or actual circumstances of usage. Canon Hongkong Company Limited shall not be responsible for any loss or damage suffered by any party directly or indirectly resulting from the use of this document or any information therein. 免責聲明: 本文件內容只供參考。產品之規格及表現可因改動及實際使用情況而有所差異。佳能香港有限公司對任何一方直接或間接使用此文件或其中任何內容而遭受的虧損或損失, 將不承擔任何責任。